



INSTRUCTIONS



NEW PROPUR™ PROMAX™ COUNTERTOP

FOR TECHNICAL SUPPORT PLEASE CALL

1-800-544-3533

OR email:

customerservice@propurusa.com



NEW PROPUR™ COUNTERTOP WATER FILTER SYSTEM WITH PROMAX™ FILTER TECHNOLOGY

Model PMC3000



Designed to fit most faucets with removable aerator
No power required. Just connect to your faucet
Easy and quick installation – no tools required

READ COMPLETELY BEFORE INSTALLING OR USE.

- For use with cold potable water only
- Do not use water source that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the System
- For specific health requirements, consult your healthcare professional

1.0 INSTALLATION

1. Select a location for the System

The System is designed to be free standing near a sink so that water from the System outlet can drain into your sink.

1. Connect the System (**filter is pre-installed**)

Remove the aerator from your faucet should it have one.

Screw the diverter valve (1) onto your faucet if a male thread is visible.

If not, use the adapter (7) provided with your System and screw diverter valve to the adapter. Do not over-tighten. If your faucet does not have a removable aerator or the adaptor does not fit, please contact our technical department to request a universal faucet adapter (8 optional) as shown above at 1-800-544-3533 x27 or email customerservice@propurusa.com.

2.0 Conditioning The Filter

Your System should now be ready to condition the filter.

1. To avoid issues caused by air locks, hold the unit upside-down in the kitchen sink.
2. Turn on the cold tap with low to moderate pressure, rotate the selector(2) on the diverter valve to allow water to slowly fill the unit for the first time. It may take a few minutes for water to flow through the outlet arm (5).
3. Once water begins to flow through the outlet, place System on counter next to sink and allow water to run to waste for a minimum of 10 minutes, or 3 gallons*. This will expel any trapped air, remove any carbon fines from the manufacturing process, and condition the filter for use

***DO NOT DRINK THIS WATER. ALLOW IT TO GO TO WASTE.**

4. After this procedure is complete, the System is now ready for use.

3.0 How To Use Your System

1. When you desire water from your System, rotate the selector (2) on the diverter valve (2) allowing water to flow through the System and exit the outlet (spout). May drip after you turn off diverter or faucet for a few drips.

4.0 How To Replace The Filter Cartridge

1. With the cold tap turned off, hold the filter unit upside-down over the sink.
2. Unscrew the body (4), which will be full of water, from the base (6). The cartridge (9) can now be removed by gently pulling it away from the base (6). The filter cartridge does NOT require cleaning.
3. After a new filter cartridge (9) has been re-installed, recondition the filter as described in 2.0. Hand tighten the body (4) onto the base (6).

ProMax™ Countertop System Specifications

Type of installation: Counter top
Maximum Working Pressure: 860 Kpa (125 psig)
Minimum Working Pressure: 62 Kpa (10 psig)
Maximum Working Temperature: 38° C (100° F)
Minimum Working Temperature: 5° C (41° F)
Recommended Flow Rate: 0.2 – 1.0 gpm
Contaminant Reduction: Refer to Lab Report
Filter Life Expectancy: Up to 1 year
Replacement filter: PMC34RF

FAQ's

How do I know when to replace my filter cartridge?

- When the flow rate diminishes
- When you notice a change in taste or odor
- Approaching a years' usage

What if I don't use the System for an extended period of time

- We recommend you drain your System and remove the filter element
- When ready to use, just reinstall the filter and flush for about 10 minutes before use

How long will my filter last before needing to be replaced

- The actual life expectancy of your filter will vary depending on the specific chemistry and level of contaminants present in your water source



ProMax™
FILTER TECHNOLOGY™

Shower Filter
Counter Top
Under Counter
Whole House
Filtration Systems

PROPUR™ LIMITED WARRANTY

Lincoln-Remi Group, LLC d/b/a Propur ("PP") sells its products with the intent that they are free from defects. PP warrants to the original retail purchaser/consumer that its products will be free of defects in material and workmanship under normal use for a period one (1) year for the Propur™ Countertop and 9 months for the ProMax™ filter cartridge ("Warranty Period"). PP will replace or repair any product, at its sole discretion, during the Warranty Period. Any damage caused by misuse or abuse; accident; improper installation; dropped product; failure to provide recommended maintenance; transportation damage; neglect; environmental conditions; or any other conditions whatsoever that are beyond the control of PP are excluded from this warranty. This express limited warranty shall be the sole and exclusive warranty. **ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS OR FITNESS FOR ANY PARTICULAR PURPOSE OR ANY OTHER POTENTIAL OBLIGATION ON THE PART OF PP WITH RESPECT TO PRODUCTS SOLD BY PP ARE DISCLAIMED. EXCEPT FOR ANY EXPRESS WARRANTIES, ALL PROPUR PRODUCTS ARE SOLD "AS-IS".** PP shall not be held liable for any incidental, consequential or special damages of any sort whatsoever. The liability of PP is limited to the original retail purchaser and to the repair or replacement of defective parts during the Warranty Period. No refunds will be given at any time. The liability of PP terminates upon the expiration of the Warranty Period or transfer of product ownership.

To obtain warranty service on your Propur product, mail the product with your dated sales receipt as proof of purchase, postpaid, to the following address:

Propur, 1200 Benstein Rd, Commerce Twp, MI 48390. NO C.O.D.'s
This warranty provides you with specific legal rights. You may have additional rights which may vary from country to country. Because of individual country laws and regulations, some of the above limitations and exclusions may not apply to you.